




Bubble Wall & Floor

Bubble Wall








* not included with Bubble Wall



1. FLOOR OPTION

Not available for Bubble Wall












Installation manual Senso Burner (I1495)

10

2. WALL OPTION





Installation manual Senso Burner (I1495)